



It's not magic, it's engineering.®

GENIEMAT® TMIP

Installation Instructions

Patents: US 8,113,495 CA 2,505,938

GenieMat TMIP are a complete vibration isolation system for your treadmill composed of two pairs of front and rear isolation pads.

The 18" x 5" front pads are sized to accommodate the change in position of the front wheels while maximizing stability. Rear pads are 5" x 7" and support the lower weight back end of the treadmill.

PROPER INSTALLATION AND POSITIONING OF **GenieMat TMIP** ARE AS FOLLOWS:

1. Clean the floor area under and around the treadmill removing any obstructions, cables, dirt, grease, etc.
2. Reset treadmill incline to the minimum setting and place a mark on the floor at the desired front wheel position.
3. Adjust treadmill inclination to the maximum setting and again place a mark on the floor at this rear front wheel position.
4. Measure the distance between the two marked points above. Subtract this distance from 15.75" (the length of the channel in the front pad).
5. Divide the resulting excess distance by 2. By measuring this distance from the front and rear of the channel you have determined the position of your minimum and maximum incline wheel positions. Mark these locations in the channel of the front pad.
6. Reset the treadmill inclination to minimum setting and install the front pads, positioning the wheel on the full forward location marked in step 3.
7. Install the rear pads such that the foot of the treadmill is positioned in the center as much as possible.
8. Use of the treadmill can cause movement of wheel and mount positions on the **GenieMat TMIP**. As a minimum maintenance procedure the treadmill should be centered on the pads weekly or as required.



CONTACT US

For Your Project Specific Questions
T. 416.449.0049 | E. info@pliteq.com

© Pliteq Inc. 2018.

®™ Trademarks of Pliteq Inc. The information provided is accurate to the best of our knowledge at the time of issue. However, we reserve the right to make changes when necessary without further notification. Suggested application may need to be modified to conform with local building codes and conditions. We cannot accept responsibility for products that are not used, or installed, to our specifications. All listed dimensions are nominal.



www.pliteq.com